


EG

QUICK GUIDE

This document is a concise version of the model manual. This document is not meant to be a replacement of the manual. To download the full manual please scan the QRcode below or locate the data label on the model and scan the QRcode.






Construction and dimensional features


Refer to the drawing supplied with the model.

Example:



Wiring diagrams

General diagram




For other connections refer to the diagram printed on the inside of the motor-fan box.

The thermo-contacts (TK) must be connected to the control circuit.

For further information refer to the diagrams supplied with the model.

On standard EG models: on models supplied with the wiring in the junction box, remove the cover to make the connection.

On Junior, Jumbo and Giant models: on request, models can be supplied with wiring in a junction box or electrical cabinet.






It is mandatory to use power cables with a minimum cross-section as indicated in Tab. 1. Please refer to the technical standards in force in the country of installation, based also on the way the cables are laid and their length and type.

Nominal current [A]	Power cable cross-section [mm²]
11	1.5
15	2.5
20	4
26	6
36	10
48	16
64	25
80	35
95	50
150	95
170	120

Table 1

To minimise the risk of indirect contact, the electrical system can be earthed using the pin on the front. On standard EG models please lift the front cover to locate the pin.



Notes



Modine CIS Italy S.r.I. 33050 Pocenia - Udine - Italy Via Giulio Locatelli, 22

Tel. +39 0432.772.001 Fax +39 0432.779.594

www.modine.com

Link to user manuals:



https://www.modinecoolers.com/documents/